

# **Technical brochure**

# Pressure controls, Type KP



Features

- Ultra-short bounce times
- Reduces wear to a minimum and increases reliability
- Manual control
- Electrical contact function can be tested without the use of tools
- KP 2 with low differential for low-pressure regulation

KP pressure controls are for use in refrigeration and air conditioning systems to give protection against excessively low suction pressure or excessively high discharge pressure.

KP pressure controls are also used for starting and stopping refrigeration compressors and fans on air-cooled condensers.

A KP pressure control can be connected directly to a single-phase AC motor of up to approx. 2 kW or installed in the control circuit of DC motors and large AC motors.

KP pressure controls are fitted with a singlepole double-throw (SPDT) switch. The position of the switch is determined by the pressure control setting and the pressure at the connector.

KP pressure controls are available in IP 30 and IP 44 enclosures.


- KP 6 for HP refrigerants (R 410A, CO<sub>2</sub>)
- KP 6, 7 and 17 with fail-safe bellows element
- Vibration and shock resistant
- Compact design
- Fully welded bellows element
- High reliability both electronically and mechanically

Technical brochure	Pressure controls, type KP	Dantoss
Approvals	CE-marked in accordance with LVD 73/23/EC and EN 60947-4-5 for sale in Europe.	KP 1, 2, 6, 7 and KP 17: CE marked in accordance with PED 97/23/EC, category IV, safety equipment and EN 12263 China Compulsory Certificate, CCC
Ship approvals	Germanischer Lloyd, GL Underwriters Laboratories Inc., US – UL Det Norske Veritas, Norway, DNV Registro Italiano Navale, RINA	Bureau Veritas, BV Lloyd's Register, LR Russian Maritime Register of Shipping, RMRS
Technical data	Ambient temperature $-40 \rightarrow +65^{\circ}C$ (+80°C for max. 2 hours).	Contact systems
		SPDT
	DIN-approved units: -25 → +65°C (+80°C for max. 2 hours).	
	Max. working pressure LP: PB = 17 bar	Low pressure (LP)
	HP: PB = 35 bar	SPDT
	KP 6: PB = 46.5 bar	4 • • • • • • •
	Max. test pressure	
	LP: $p' = 20$ bar	
	HP: p' = 35 bar KP 6: p' = 46.5 bar	High pressure (HP)
	$r_{\rm F}$ 0. $p = +0.5$ bai	SPST
	Contact load	
	Alternating current: AC1: 16 A, 400 V	
	AC1: 16 A, 400 V AC3: 16 A, 400 V	Dual pressure
	Direct current:	
	DC13: 12 W, 220 V control current	SPDT+LP signal
	Properties according to EN 60947: Wire dimensions	
	solid/stranded 0.75 - 2.5 mm <sup>2</sup>	Dual pressure
	flexible, w/out ferrules 0.7 - 2.5 mm <sup>2</sup>	(LP/HP)
	flexible, with ferrules 0.5 - 1.5 mm <sup>2</sup>	
	Tightning torquemax. 2 NmRated impulse voltage4 kV	SPDT+LP+HP signal
	Pollution degree 3	
	Short circuit protection, fuse 16 Amp	
	Insulation 400 V IP 30/44	
	11 50/44	
	Cable connection The cable entry can be used for $6 \rightarrow 14$ mm dia.	Dual pressure Sector (LP/HP)
	cables. A Pg 13.5 screwed cable entry can also be used	
	for $6 \rightarrow 14$ mm cable. With $8 \rightarrow 16$ mm cable a standard Pg 16 screwed cable entry can be used.	bracket. The bracket must be fixed to the unit so that all unused holes are covered.
	Enclosure IP 30 to EN 60529 / IEC 529	KP pressure controls with auto reset are supplied with top cover. For KP pressure controls with manual reset, the top cover must be separately
	Enclosure IP 30 is obtained when the units	ordered.
	without top cover are mounted on a flat surface or bracket. The bracket must be fixed to the unit	IP 55 to EN 60529 / IEC 529
	so that all unused holes are covered.	IP 55 is obtained when the KP pressure controls are mounted in an IP 55 enclosure, (code no.
	IP 44 to EN 60529 / IEC 529	060-033066 for single pressure controls and
	Enclosure IP 44 is obtained when the units with top cover are mounted on a flat surface or	code no. 060-035066 for dual pressure controls
	with top cover are mounted on a hat surface of	IP 55 enclosure has to be ordered separately.

# Materials in contact with the medium

Unit type	Material
KP 1, 2, 5, 6, 7, 15 and 17	Tinbronze, no. CW452K, EN 1652 Free cutting steel, no. 1.0737 / 1.0718, EN 10277
KP 1A, 5A, 6, 7A and 15A only	Stainless steel 18/8, no. 1.4306, EN 10088-2 Free cutting steel, no 1.0737, EN 10277 Cold forming steel, no 1.0338, EN 10139 Steel, no 1.0308, EN 10305 Free cutting steel, no 1.0715, EN10277 Free cutting steel, no. 1.0718, EN 10277 Aluminium, no AW-3005,EN 573

# Ordering



Danfoss

		Low pressure (LP)		High pressure (HP)		Reset			Code no.		
Pressure	Туре	Regulating range bar	Differential ∆p bar	Regulating range bar	Differential ∆p bar	Low pressure LP	High pressure HP	Contact system	¹/₄ in. 6 mm flare	¹/₄ in. ODF solder	6 mm ODF solder

#### For fluorinated refrigerants

	1	-		1	1	1	1				
Low	KP 1	$-0.2 \rightarrow 7.5$	$0.7 \rightarrow 4.0$			Aut.			060-110166 <sup>3)</sup>	060-111266 <sup>3)</sup>	060-111066 <sup>3)</sup>
Low	KP 1	$-0.2 \rightarrow 7.5$	$0.7 \rightarrow 4.0$			Aut.			060-114166 <sup>1)3)</sup>		
Low	KP 1	$-0.9 \rightarrow 7.0$	Fixed 0.7			Man.		SPDT	060-110366	060-111166	060-110966
Low	KP 2	$-0.2 \rightarrow 5.0$	$0.4 \rightarrow 1.5$			Aut.		SPDI	060-112066 <sup>3)</sup>		060-112366 <sup>3)</sup>
High	KP 5			8 → 32	1.8 → 6.0		Aut.		060-117166 <sup>3)</sup>	060-117966 <sup>3)</sup>	060-117766 <sup>3)</sup>
High	KP 5			8 → 32	Fixed 3		Man.		060-117366	060-118066	060-117866
Dual	KP 15	$-0.2 \rightarrow 7.5$	$0.7 \rightarrow 4.0$	8 → 32	Fixed 4	Aut.	Aut.		060-124166 <sup>3)</sup>	060-125466 <sup>3)</sup>	
Dual	KP 15	$-0.2 \rightarrow 7.5$	$0.7 \rightarrow 4.0$	8 → 32	Fixed 4	Aut.	Man.	SPDT +	060-124366		
Dual	KP 15	$-0.2 \rightarrow 7.5$	$0.7 \rightarrow 4.0$	8 → 32	Fixed 4	Aut.	Man.	LP	060-114866 <sup>1)</sup>		
Dual	KP 15	$-0.9 \rightarrow 7.0$	Fixed 0.7	8 → 32	Fixed 4	Man.	Man.	signal	060-124566		
Dual	KP 15	$-0.9 \rightarrow 7.0$	Fixed 0.7	8 → 32	Fixed 4	Conv.2)	Conv.2)	1	060-126166		
Dual	KP 15	$-0.2 \rightarrow 7.5$	$0.7 \rightarrow 4.0$	8 → 32	Fixed 4	Aut.	Aut.	SPDT +	060-126566 <sup>3)</sup>	060-129966 <sup>3)</sup>	
Dual	KP 15	$-0.2 \rightarrow 7.5$	$0.7 \rightarrow 4.0$	8 → 32	Fixed 4	Aut.	Man.	LP and	060-126466	060-128466	
Dual	KP 15	$-0.2 \rightarrow 7.5$	$0.7 \rightarrow 4.0$	8 → 32	Fixed 4	Conv.2)	Conv.2)	HP	060-115466 <sup>3)</sup>	060-001066 <sup>3)</sup>	
Dual	KP 15	$-0.9 \rightarrow 7.0$	Fixed 0.7	8 → 32	Fixed 4	Conv.2)	Conv.2)	signal	060-122066		

		Low pressure (LP)		High pressure (HP)		Reset	Co		e no.
Pressure	Туре	Regulating range bar	Differential ∆p bar	Regulating range bar	Differential ∆p bar	LP/HP	Contact system	M10 × 0.75	1 m cap. tube with M10 × 0.75

# For fluorinated refrigerants and R 717 (NH,)

Low	KP 1A	$-0.2 \rightarrow 7.5$	$0.7 \rightarrow 4.0$			Aut.		060-116266	060-116066 <sup>3)</sup>
Low	KP 1A	$-0.9 \rightarrow 7.0$	Fixed 0.7			Man.	CDDT		060-116166
High	KP 5A			8 → 32	1.8 → 6.0	Aut.	- SPDT -		060-123066 <sup>3)</sup>
High	KP 5A			8 → 32	Fixed 3	Man.		060-115366	060-123166
Dual	KP 15A	$-0.2 \rightarrow 7.5$	$0.7 \rightarrow 4.0$	8 → 32	Fixed 4	Aut./Aut.	SPDT + LP and HP	060-129566	060-129366 <sup>3)</sup>
Dual	KP 15A	$-0.2 \rightarrow 7.5$	$0.7 \rightarrow 4.0$	8 → 32	Fixed 4	Aut./Man.	signal	060-129666	060-129466
Dual	KP 15A	$-0.9 \rightarrow 7.0$	Fixed 0.7	8 → 32	Fixed 4	Conv./Conv. <sup>2)</sup>	SPDT LP signal		060-128366

 $^{\scriptscriptstyle 1)}~$  Pressure controls with gold-plated contacts <sup>2)</sup> Conv.: optional automatic or manual reset

<sup>3)</sup> Enclosure IP 44


Accessories for KP pressure controls with  $M10 \times 0.75$  connections: Weld connections: M10  $\times$  0.75 nut and  $\varnothing$ 6  $\times$  150 mm seamless steel pipe, Steel cap. tube: 1 m with  $2 \times M10 \times 0.75$  nuts, Steel cap. tube: 1 m with  $1 \times M10 \times 0.75$  and G  $\frac{3}{8}$  nut, Adaptor: M 10  $\times$  0.75  $^{1}\!/_{_{4}}$  to  $^{1}\!/_{_{8}}$  NPT int. thread, IP 55 enclosure for single pressure controls, IP 55 enclosure for dual pressure controls,

For other accessories: see "Spare parts and accessories", RX5AB302


code no. 060-005766 code no. 060-007866 code no. 060-008266 code no. 060-014166 code no. 060-033066 code no. 060-035066

## Ordering (continued)

# Pressure control setting with convertible reset



<sup>1)</sup> Factory setting



# Pressure controls with EN 12263 and DIN 32733 approval<sup>1)</sup>

		Low pressure (LP)		High pressure (HP)		Reset		Code no.	
Pressure	Type <sup>2)</sup>	Regulating range bar	Differential ∆p bar	Regulating range bar	Differential ∆p bar	LP/HP	Contact system	'/₄in. 6 mm flare	6 mm ODF solder

#### For fluorinated refrigerants

Low	KP 1	$-0.2 \rightarrow 7.5$	0.7 → 4.0			Aut.	SPDT	060-110166 <sup>3)</sup>	060-111066 <sup>3)</sup>
Low	KP 1	$-0.9 \rightarrow 7$	Fixed 0.7			Man.	SPDT	060-110366	060-110966
Low	KP 1	$-0.5 \rightarrow 3.0$	Fixed 0.7			Aut.	SPDT		060-111766
Low	KP 2	$-0.2 \rightarrow 5$	$0.4 \rightarrow 1.5$			Aut.	SPDT	060-112066 <sup>3)</sup>	060-112366 <sup>3)</sup>
High	KP 6W			8 → 42	4→10	Aut.	SPDT	060-519066 <sup>3)</sup>	
High	KP 6B			8→42	Fixed 4	Man.	SPDT	060-519166	
High	KP 7W			8 → 32	4→10	Aut.	SPDT	060-119066 <sup>3)</sup>	060-120366 <sup>3)</sup>
High	KP 7B			8 → 32	Fixed 4	Man.	SPDT	060-119166	
High	KP 7S			8 → 32	Fixed 4	Man.	SPDT	060-119266 <sup>3)</sup>	
Dual	KP 7BS			8 → 32	Fixed 4	Man. / Man.	SPST	060-120066	
Dual	KP 17W	-0.2 → 7.5	$0.7 \rightarrow 4$	8 → 32	Fixed 4	Aut. / Aut.	SPDT + LP and HP signal	060-127566 <sup>3)</sup>	060-127666 <sup>3)</sup>
Dual	KP 17W	$-0.2 \rightarrow 7.5$	$0.7 \rightarrow 4$	8 → 32	Fixed 4	Aut. / Aut.	SPDT+ LP signal	060-126766 <sup>3)</sup>	
Dual	KP 17B	-0.2 → 7.5	$0.7 \rightarrow 4$	8 → 32	Fixed 4	Aut. / Man.	SPDT	060-126866	060-127466
Dual	KP 17WB	-0.2 → 7.5	$0.7 \rightarrow 4$	8 → 32	Fixed 4	Aut./Conv. <sup>5</sup> )	SPDT + LP and HP signal	060-539766 <sup>3)4)</sup>	

# Pressure controls with EN 12263 and DIN 32733 approval<sup>1)</sup>

		Low pressure (LP)		High pressure (HP)		Reset		Code no.	
Pressure	Type <sup>2)</sup>	Regulating range bar	Differential ∆p bar	Regulating range bar	Differential ∆p bar	LP/HP	Contact system	M10 × 0.75	1 m cap. tube with M10 × 0.75

## For ammonia

Low	KP 1A	-0.2 → 7.5	0.7→4.0			Aut.	SPDT	060-116266	060-116066 <sup>3)</sup>
Low	KP 1A	$0.9 \rightarrow 7$	Fixed 0.7			Man.	SPDT		060-116166
High	KP 7ABS			$8 \rightarrow 32$	Fixed 4	Man./Man.	SPST		060-120566

 Meets the requirements in VBG 20 dealing with safety equipment and excess pressures KP 1, 2, 6, 7 and KP 17 are CE marked acc. to PED, Pressure Equipment Directive
 W = Wächter (pressure), B = Begrenzer (pressure control with ext. reset), S = Sicherheitsdruckbegrenzer (pressure control with int. reset) 2)

3) Enclosure IP 44


4) Factory setting: LP side: Range 1 bar Pe, Diff. 1 bar; HP side: Range 18 bar Pe, Diff. 4 bar fixed

<sup>5)</sup> Conv.: optional automatic or manual reset




# **Design / Function**

**Technical brochure** 






Capillary tube



Capillary tube for KP 1A, 5A and 15A

- 1. Low pressure (LP) setting spindle
- 2. Differential setting spindle, LP
- 3. Main arm
- High pressure (HP) setting spindle
- High pressure (HP)
  Main spring
  Differential spring
- 9. Bellows
- 10. LP connection 11. HP connection
- 12. Switch
- 13. Terminals
- 14. Earth terminal
- 15. Cable entry
- 16. Tumbler
- 18. Locking plate
- 30. Reset button



1/4 in./6mm

KP 15

○=

12mm KP 1

The switch in the KP has a snap-action function and the bellows moves only when the cut-in or cut-out value is reached.

The bellows becomes connected to the low or high pressure side of the plant through connection (10) or (11).

The design of the KP pressure control affords the following advantages:

- high contact load
- ultra-short bounce time •
- high resistance to pulsation
- vibration resistance up to 4 g in the range • 0-1000 Hz
- long mechanical and electrical life



**Design** (continued) KP1, KP1A, KP2, KP6, KP6A, KP7 and KP17 units with designation W, B or S have been tested and approved by TÜV, Rheinland in accordance with EN 12263.

- W = Wächter (pressure control)
- B = Begrenzer (pressure control with external reset)
- S = Sicherheitsdruckbegrenzer (pressure control with internal reset).

KP6, KP6A, KP7 and KP17 have a double bellows: an outer bellows and a regulating bellows. When system pressure exceeds the set value, the KP will automatically stop the plant. The double bellows system prevents loss of charge in the event of bellows rupture.


A rupture in the inner bellows will cause the control cut-out pressure to fall about 3 times less the set value, thus the refrigeration plant compressor will stop.

A rupture in the outer bellows will cause the control cut-out pressure to fall to about 3 bar under the set value, thus providing a fail-safe function.


Versions with designation W or AW cut in again automatically when the pressure has fallen to the set value minus the differential.

Versions with designation B or AB can be cut in manually with the external reset button when the pressure in KP1 has raised 0.7 bar above set value and in KP6 and KP7 has fallen 4 bar under the set value.


Versions with designation S or AS can be cut in manually with the internal reset arm when the pressure has fallen 4 bar under the set value. All KP pressure controls, including those which are PED-approved, operate independently of changes in the ambient temperature around the control housing. Therefore the set cut-out pressure and differential are held constant provided the permissible ambient temperatures are not exceeded.



KP 7W, flare



- 1. Pressure setting spindle
- 2. Differential setting spindle
- 3. Main arm
- 15. Cable entry 18. Locking plat
- 18. Locking plate 25. Int. reset arm
- 30. Ext. reset button





# Terminology

- Reset 1. Manual reset:
- Units with manual reset can only be reset during operation by activation of the reset button.
- 2. Automatic reset: After operational stop, these units reset automatically.
- 3. Convertible reset: Units with optional reset can be activated by automatic and/or manual reset.

#### Permissible working pressure

The permissible working pressure is determined by the pressure that can be safely allowed in the refrigerating system or any of the units within it. The permissible working pressure is designated PB (Der zulässige Betriebsüberdruck).

#### Test pressure

The test pressure is the pressure used in strength tests and/or leakage tests on refrigerating systems or individual parts in systems. The test pressure is designated p'.

#### "Snap function"

A certain contact force is maintained until irrevocable "snap" is initiated. The time during which the contact force approaches zero is thus limited to a very few milliseconds. Therefore contact bounce cannot occur as a result of, for example, slight vibrations, before the cut-out point. Contact systems with "Snap function" will change over even when micro-welds are created between the contacts during cut-in. A very high force is created during cut-out to separate the contacts. This force immediately shears off all the welds. Thus the cut-out point of the unit remains very accurate and completely independent of the magnitude of the current load.

#### Setting

*Pressure controls with automatic reset - LP:* Set the LP start pressure on the "CUT-IN" scale (range scale).

One rotation of the low pressure spindle ~ 0.7 bar.

Set the LP differential on the "DIFF" scale. One rotation of the differential spindle ~ 0.15 bar. The LP stop pressure is the LP start pressure minus the differential.

#### Note:

The LP stop pressure must be above absolute vacuum  $(p_a = -1 \text{ bar})!$ 


If with low stop pressure the refrigeration compressor will not stop, check to ensure that the differential value has not been set too high! Pressure controls with automatic reset - HP: Set the HP pressure on the "CUT-OUT" scale. One rotation of the HP spindle ~ 2.3 bar. Set the HP differential on the "DIFF" scale. One rotation of the differential spindle ~ 0.3 bar. The HP start pressure is the HP stop pressure minus the differential.


Start and stop pressures for both the LP and HP sides of the system should always be checked with an accurate pressure gauge.

### *Pressure controls with manual reset* Set the stop pressure on "CUT-OUT" scale (range scale).

Low pressure controls can be manually reset when the pressure is equal to the stop pressure plus the differential.

High pressure controls can be manually reset when the pressure is equal to the stop pressure minus the differential.





Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Danfoss