ART-37

DuPont[™] Suva[®] refrigerants

Retrofit Guidelines for DuPont™ Suva® HFC Refrigerants

Suva® 134a for R-12 Retrofit Suva® 404A (HP62) and Suva® 507 for R-502 Retrofit Suva® 404A (HP62) and Suva® 507 for R-22 Retrofit



Retrofit Guidelines for DuPont™ Suva® HFC Refrigerants

Table of Contents

	age
Introduction	1
R-12 Replacement Choices	1
R-502 Replacement Choices	1
R-22 Replacement Choices	1
Using HFCs versus Service Refrigerants	1
Important Safety Information	2
Lubricant and Filter Drier Information Lubricants Filter Drier	2
General Retrofit Information System Modifications	2 3
Retrofit of R-12 Systems to DuPont™ Suva® 134a	4
Retrofit of R-502 Systems to DuPont™ Suva® 404A (HP62) or DuPont™ Suva® 507	. 5
Retrofit of R-22 Systems to DuPont™ Suva® 404A (HP62) or DuPont™ Suva® 507	. 6
Pressure/Temperature Charts—Introduction How to Read the Pressure/Temperature Charts How to Determine Suction Pressure, Superheat, and Subcool	. 8
Retrofit Checklist for DuPont [™] Suva [®] 134a, DuPont [™] Suva [®] 404A (HP62), or DuPont [™] Suva [®] 507	9
System Data Sheet	10
Appendix Table 1. Pressure/Temperature Chart—Suva® 134a/R-12 Table 2. Pressure/Temperature Chart—Suva® 404A (HP62)/R-502 Table 3. Pressure/Temperature Chart—Suva® 507/R-502 Table 4. Pressure/Temperature Chart—Suva® 404A (HP62)/R-22 Table 5. Pressure/Temperature Chart—Suva® 507/R-22 Table 6. Suva® 134a Physical Properties Table 7. Suva® 404A (HP62) and Suva® 507 Physical Properties Table 8. Compositions of Suva® Refrigerants	12 13 14 15 16 16
DuPont Technical Assistance and Other Information back page	ge

Introduction

With the phaseout of CFCs and HCFCs, existing refrigeration and air-conditioning equipment operating with CFCs and HCFCs will ultimately need to be either replaced with new equipment or retrofitted with alternative refrigerants. Some service technicians and equipment owners have elected to retrofit to hydrofluorocarbon (HFC) refrigerants such as DuPontTM Suva® 134a, Suva® 404A (HP62), or Suva® 507.

Using these procedures, R-12, R-502, and R-22 equipment can be safely and efficiently retrofitted with HFC-based Suva® refrigerants, allowing the equipment to continue in service for the remainder of its useful life. These retrofit guidelines are intended for equipment containing positive displacement compressors.

R-12 Replacement Choices

Suva® 134a (R-134a) is the long-term HFC replacement for R-12 in new equipment and for retrofitting some R-12 systems such as supermarket display cases, commercial refrigeration and airconditioning equipment, appliances, and transport refrigeration equipment. In stationary equipment Suva® 134a is recommended for retrofit of equipment with evaporator temperatures above 20°F (-7°C) to ensure best performance. Suva® 134a may be used in existing equipment at lower evaporator temperatures, but it can exhibit reduced capacity compared with R-12 unless system modifications are made.

R-502 Replacement Choices

- Suva® 404A (HP62) is widely recognized as the preferred HFC replacement for R-502 in new equipment and for retrofitting R-502 systems such as supermarket and food service, industrial freezing, and some transport refrigeration. Suva® 404A (HP62) offers the closest HFC match to R-502 performance and can be used over the full R-502 operating range. Suva® 404A (HP62) also provides lower compressor discharge temperatures than R-502, which can increase compressor reliability and life.
- Suva® 507 (R-507) is an HFC replacement option for R-502 in new equipment and for retrofitting R-502 systems. Suva® 507 can also be used over the full R-502 operating range, and provides lower compressor discharge temperatures than R-502, which can increase compressor reliability and life.

• Suva® 407C (R-407C) is also an HFC retrofit option for R-502 in certain equipment. Refer to ART-34 "Retrofit Guidelines for Suva® 407C" for details.

R-22 Replacement Choices

Suva® **404A** (**HP62**) and **Suva**® **507** (**R-507**) are HFC retrofit options for R-22 refrigeration equipment, especially for medium and low temperature applications. These products will provide similar cooling capacity at evaporator temperatures in the range of 30°F to 50°F (-1°C to 10°C). At evaporator temperatures below 30°F (-1°C), the cooling capacity is greater than R-22. At 0°F (-18°C) the capacity is about 6% higher; and at -40°F (-40°C) the capacity is about 30% higher.

At evaporator temperatures above $10^{\circ}F$ ($-12^{\circ}C$) there is an energy efficiency penalty of about 5 to 10%. At evaporator temperatures below $10^{\circ}F$ ($-12^{\circ}C$) Suva® 404A (HP62) and 507 have similar energy efficiency, increasing to about +20% at $-40^{\circ}F$ ($-40^{\circ}C$).

Suva® **404A** (**HP62**) and **507** will have higher discharge pressure than R-22, but lower compression ratios; and also lower discharge temperature.

• Suva® 407C (R-407C) should also be considered as a retrofit option for R-22 in medium temperature equipment. It will provide similar cooling capacity and energy efficiency at evaporator temperatures above 25°F (4°C). Refer to ART-34 "Retrofit Guidelines for Suva® 407C" for details

Using HFCs versus Service Refrigerants

Refrigerants such as Suva® MP39, Suva® 409A, Suva® HP80 and Suva® 408A are often selected for retrofit instead of HFCs because these service refrigerants typically involve an easier and more cost-effective retrofit procedure while providing improved performance over the CFCs they replace. The compressor oil change procedures are typically less complicated with the service refrigerants, which results in lower retrofit costs. Refer to DuPont bulletin ART-36 "Retrofit Guidelines for Suva® Service Refrigerants" for full details.

Important Safety Information

Like CFCs, Suva® refrigerants are safe when handled properly. However, any refrigerant can cause injury or even death when mishandled. Please review the following guidelines before using *any* refrigerant.

- Do not work in high concentrations of refrigerant vapors. Always maintain adequate ventilation in the work area. Do not breathe vapors. Do not breathe lubricant mists from leaking systems. Ventilate the area well after *any* leak before attempting to repair equipment.
- Do not use handheld leak detectors to check for breathable air. These detectors are not designed to determine if the air is safe to breathe. Use oxygen monitors to ensure adequate oxygen is available to sustain life.
- Do not use flames or torches to search for leaks. Do not use flames in high concentrations of refrigerant. Open flames release large quantities of acidic compounds in the presence of all refrigerants, and these compounds can be hazardous. Do not use torches as leak detectors. Old halide torches detect chlorine, which may not be present with new refrigerants. Use an electronic leak detector designed to find the refrigerants you are using.

If you detect a visible change in the size or color of a flame when using torches to repair equipment, **stop work immediately and leave the area**. Ventilate the work area well and stop any refrigerant leaks before resuming work. These flame effects may be an indication of very high refrigerant concentrations, and continuing to work without adequate ventilation may result in injury or death.

Note: Any refrigerant can be hazardous if used improperly. Hazards include liquid or vapor under pressure, and frostbite from the escaping liquid. Overexposure to high concentrations of vapor can cause asphyxiation and cardiac arrest. Please read all safety information before handling any refrigerant.

For more detailed information on the properties, uses, storage, and handling of Suva® refrigerants, see DuPont Technical Bulletin P-134a or P-HP, or other literature specific to these products. Refer to the appropriate Material Safety Data Sheet (MSDS) for more safety information about each refrigerant. DuPont Safety Bulletin AS-1 gives additional information for safe handling of refrigerants.

Lubricant and Filter Drier Information

Lubricants

Lubricant selection is based on many factors, including compressor wear characteristics, material compatibility, and lubricant/refrigerant miscibility that can affect oil return to the compressor. Before starting a retrofit, consult the compressor manufacturer to determine the correct lubricant for your compressor. Other information sources are DuPont Refrigerant Distributors, lubricant manufacturers, and system manufacturers.

Polyol ester (POE) lubricants must be used with Suva® 134a, Suva® 404A (HP62) or Suva® 507 refrigerants. These lubricants are available from DuPont Refrigerant Distributors. To provide optimum oil return, equipment using mineral oil or alkylbenzene must be flushed to remove at least 95% of these oils. See the retrofit procedures below for more information.

Special care should be taken when handling POE lubricants because of their tendency to absorb water. Minimize contact with air and store the lubricant in a sealed container.

Filter Drier

Change the filter drier during the retrofit. This is a routine practice following system maintenance. There are two types of filter driers commonly used, solid core and packed bead.

Replace the drier with the same type you currently use. The drier label will show which refrigerants can be used with that drier. Check with your DuPont Refrigerant Distributor for the correct drier to use in your system.

General Retrofit Information

System Modifications

The compositions of these Suva® refrigerants have been selected to provide performance comparable with the refrigerants they are replacing in terms of both capacity and energy efficiency. As a result, minimal system modifications are anticipated with retrofitting. Suva® 404A (HP62) and Suva® 507 are near-azeotropes at most temperatures, therefore the vapor composition in the refrigerant cylinder is slightly different from the liquid composition. This small difference will not affect performance in direct expansion systems, but it could affect performance in systems with flooded evaporators.

You should consult the original equipment manufacturer for recommendations concerning the compatibility of elastomers and plastics used in their system and the new refrigerant. Although many system components used with CFCs are also compatible with Suva® refrigerants, there are exceptions that, if not replaced, can cause refrigerant leakage or system failure.

Field experience has shown that some systems retrofitted directly from R-502 to Suva® 404A (HP62) or Suva® 507 can have increased leakage due to shrinkage of elastomers (o-rings, gaskets) following removal of the R-502. This same situation might exist in an R-22 retrofit. Replacement of these elastomers may add additional cost and time to the retrofit.

Retrofits of R-12 or R-502 systems with other alternative refrigerants such as HCFC-22 may require more extensive modifications to the existing equipment, such as replacement of the compressor with multistage compressors or use of liquid injection. For some systems this additional cost may be large. Suva® refrigerants provide the service contractor and equipment owner with a cost-effective way to retrofit an existing system.

Note: Suva® refrigerants were not designed for use in conjunction with other refrigerants or additives that have not been clearly specified by DuPont or the equipment manufacturer. Mixing Suva® refrigerants with other refrigerants, may have an adverse effect on system performance. "Topping off" a different refrigerant with any Suva® refrigerant is not recommended.

Refrigerant Recovery Information

Most recovery or recycle equipment used for R-12, R-502, or R-22 can be used for Suva® refrigerants. Use standard procedures to avoid cross-contamination when switching from one refrigerant to another. Consult the equipment manufacturer for specific recommendations.

In the United States, DuPont will take back for reclaim the Suva® refrigerants discussed in this bulletin.

What to Expect Following a Retrofit

These tables show approximate system performance changes following a retrofit. These values are general guidelines for system behavior, and actual performance will vary with each system.

Suva® 134a is compared to R-12, Suva® 404A (HP62) and Suva® 507 are compared to R-502.

DuPont™ Suva® Refrig.	Disch. Press. psi (kPa)	Suct. Press. psi (kPa)	Disch. Temp. °F(°C)	Refrig. Cap'y. (%)
134a	+10 (69.8)	-2 (-13.8)	-10 (-5.6)	-10
404A(HP62)	+20 (+137.9)	Same	10 (5.6)	Same
507	+30 (+206.8)	Same	-15 (+8.3)	Same

Suva[®] 404A (HP62) is compared to R-22 (evap. temp. = 0° F [-18° C]). **Note:** Suva[®] 507 provides performance very similar to 404A (HP62).

DuPont™	Disch. Press. psi(kPa)	Suct.	Compression	Disch.	Refrig.
Suva®		Press.	Ratio	Temp.	Cap'y.
Refrig.		psi (kPa)	(%)	°F(°C)	(%)
404A(HP6	62) +45 (+310)	+10 (+69.8)	-5	-64 (-36)	+6

How to read these tables

Example: R-12 to Suva[®] 134a retrofit. Discharge pressure with 134a will be in the range of 10 psig higher than R-12 (using discharge pressure column above).

Retrofit Summary for HFC Refrigerants

Select the **Retrofit Checklist** from the Appendix for the refrigerant you are replacing.

- 1. Establish baseline performance with CFC/HCFC.
- 2. Drain mineral oil or alkylbenzene (MO/AB) from the system and measure the volume removed. Leave the CFC/HCFC refrigerant in the system.
- 3. Add POE lubricant; use the same volume as removed in Step 2. Start up system and operate for at least 24 hours, or more if system has complex piping.
- 4. Drain POE, and repeat steps 2 and 3 at least two more times. Continue flushing until MO/AB is less than 5% by weight or as recommended by compressor manufacturer.
- 5. Recover the CFC/HCFC charge into a proper recovery cylinder.
- 6. Replace the filter/drier.
- 7. Evacuate system and check for leaks.
- Charge with Suva® refrigerant. Remove liquid only from charging cylinder for Suva® 404A (HP62) or Suva® 507.
 Typical charge is 75–90% by weight of CFC/HCFC charge.
- 9. Start up system, adjust charge size. Label system for the refrigerant and lubricant used.

Retrofit Complete

Retrofit of R-12 Systems to DuPont™ Suva® 134a

The following detailed discussion is the recommended procedure for retrofitting R-12 systems to Suva® 134a.

1. Establish baseline performance with CFC.
Collect system performance data while the
R-12 is in the system. Check for correct refrigerant charge and operating conditions. The baseline data of temperatures and pressures at various points in the system (evaporator, condenser, compressor suction and discharge, superheat and subcool, etc.) at normal operating conditions will be useful when optimizing

- operation of the system with the Suva® refrigerant. A **System Data Sheet** is included at the back of this document to record baseline data.
- Drain mineral oil or alkylbenzene from the system and measure the volume removed. Leave the CFC refrigerant in the system. If mineral oil or alkylbenzene is the existing lubricant, it will have to be drained. This may require removing the compressor from the system, particularly with small hermetic compressors that have no oil drain port. In this case, the lubricant should be drained from the suction port on the compressor after the R-12 has been properly recovered. For an effective flush, it is important to remove at least 50% of the lubricant in all cases. Larger systems may require drainage from additional points in the system, particularly low spots around the evaporator. In systems with an oil separator, any lubricant present in the separator should also be drained.

In all cases, measure the volume of lubricant removed from the system. Record this information on the Retrofit Checklist (see Appendix). Compare this volume with the compressor/system specifications to ensure that the majority of lubricant has been removed. Consult the compressor manufacturer for recommendations on allowable residual MO/AB in POE lubricant. If poor system performance is noted on start-up, an additional lubricant change may be required.

- 3. Add POE lubricant; use the same volume as removed in Step 2. Start up system and operate for at least 24 hours, or more if system has complex piping. Charge the compressor with the same volume of new lubricant as the amount you removed from the system in step 2. Use a lubricant viscosity and grade recommended by the compressor manufacturer for the Suva® refrigerant you are using; or use a similar viscosity to the oil you removed if compressor information is not available. A typical viscosity is 150 SUS or ISO 32 for many compressors.
- 4. Drain POE, and repeat steps 2 and 3 at least two more times. Continue flushing until MO/AB is less than 5% by weight or as recommended by compressor manufacturer. For an HFC refrigerant to operate properly in a retrofitted system, the residual MO/AB concentration must be very low. Repeatedly removing and replacing the POE will flush the old oil from the refrigeration system, providing that enough time is allowed with each change to circulate oil through the entire system.

- 5. **Recover the CFC charge into a proper recovery cylinder.** Use normal service practices. If the correct charge size is not known, weigh the amount of refrigerant recovered.
- 6. **Replace the filter/drier.** It is routine practice to replace the filter/drier following system maintenance. Replacement driers are available that are compatible with Suva® refrigerants. See page 2 of this manual for additional information on driers.
- 7. Evacuate system and check for leaks. To remove air or other noncondensables in the system, evacuate the system to near full vacuum (29.9 inHg vacuum [500 microns] or less than 10 kPa).
- 8. **Charge with Suva® refrigerant.** In general, the refrigeration system will require less weight of the Suva® 134a than of R-12. The optimum charge will vary depending on the system design and operating conditions. For most systems the best charge size will be 75–90% by weight of the original R-12 charge.

For best results:

- It is recommended that the system be initially charged with about 75% by weight of the original charge.
- Add the initial charge of Suva® refrigerant to the high-pressure side of the system (compressor *not* running) until the system and cylinder pressures equalize. Then connect to the low-pressure side of the system, start the compressor, and load the remainder of the refrigerant slowly to the suction side of the system.
- 9. Start up system, adjust charge size. Label system for the refrigerant and lubricant used. Start the system and let conditions stabilize. If the system is undercharged, add Suva® 134a in small amounts until the system conditions reach the desired level. See the Pressure/Temperature Charts in this bulletin to compare pressures and temperatures.

Suva® refrigerants are more sensitive to charge size than CFCs. System performance will change quickly if the system is overcharged or undercharged. Sight glasses in the liquid line can be used in most cases as a guide, but system charge should also be determined by measuring system operating conditions (discharge and suction pressures, suction line temperature, compressor motor amps, superheat, etc.). Attempting to charge until

the sight glass is clear may result in overcharging the refrigerant. Please read "How to Determine Suction Pressure, Superheat and Subcool" on page 8.

Retrofit of R-502 Systems to DuPont™ Suva® 404A (HP62) or DuPont™ Suva® 507

The following detailed discussion is the recommended procedure for retrofitting R-502 systems to Suva® 404A (HP62) or Suva® 507.

- 1. Establish baseline performance with CFC. Collect system performance data while the R-502 is in the system. Check for correct refrigerant charge and operating conditions. The baseline data of temperatures and pressures at various points in the system (evaporator, condenser, compressor suction and discharge, superheat and subcool, etc.) at normal operating conditions will be useful when optimizing operation of the system with the Suva® refrigerant. A System Data Sheet is included at the back of this document to record baseline data.
- Drain mineral oil or alkylbenzene from the system and measure the volume removed. Leave the CFC refrigerant in the system. If mineral oil or alkylbenzene is the existing lubricant, it will have to be drained. This may require removing the compressor from the system, particularly with small hermetic compressors that have no oil drain port. In this case, the lubricant should be drained from the suction port on the compressor after the R-502 has been properly recovered. For an effective flush, it is important to remove at least 50% of the lubricant in all cases. Larger systems may require drainage from additional points in the system, particularly low spots around the evaporator. In systems with an oil separator, any lubricant present in the separator should also be drained.

In all cases, measure the volume of lubricant removed from the system. Record this information on the Retrofit Checklist (see Appendix). Compare this volume with the compressor/system specifications to ensure that the majority of lubricant has been removed. Consult the compressor manufacturer for recommendations on allowable residual MO/AB in POE lubricant. If poor system performance is noted on startup, an additional lubricant change may be required.

- 3. Add POE lubricant; use the same volume as removed in Step 2. Start up system and operate for at least 24 hours, or more if system has complex piping. Charge the compressor with the same volume of new lubricant as the amount you removed from the system in step 2. Use a lubricant viscosity and grade recommended by the compressor manufacturer for the Suva® refrigerant you are using; or use a similar viscosity to the MO/AB you removed if compressor information is not available. A typical viscosity is 150 SUS or ISO 32 for many compressors.
- 4. Drain POE, and repeat steps 2 and 3 at least two more times. Continue flushing until MO/AB is less than 5% by weight or as recommended by compressor manufacturer. For an HFC refrigerant to operate properly in a retrofitted system, the residual MO/AB concentration must be very low. Repeatedly removing and replacing the POE will flush the old oil from the refrigeration system, providing that enough time is allowed with each change to circulate oil through the entire system.
- 5. **Recover the CFC charge into a proper recovery cylinder.** Use normal service practices. If the correct charge size is not known, weigh the amount of refrigerant recovered.
- 6. **Replace the filter/drier.** It is routine practice to replace the filter/drier following system maintenance. Replacement driers are available that are compatible with Suva® refrigerants. See page 2 of this manual for additional information on driers.
- 7. Evacuate system and check for leaks. To remove air or other noncondensables in the system, evacuate the system to near full vacuum (29.9 inHg vacuum [500 microns] or less than 10 kPa).
- 3. Charge with Suva® refrigerant. Remove liquid only from charging cylinder. The proper cylinder position for liquid removal is indicated by arrows on the cylinder and cylinder box. Once liquid is removed from the cylinder, the refrigerant can be charged to the system as liquid or vapor as desired. Use the manifold gauges or a throttling valve to flash the liquid to vapor if required.

In general, the refrigeration system will require less weight of the Suva® refrigerant than of R-502. The optimum charge will vary depending on the system design and operating conditions, but for most systems the best charge size will be 75–90% by weight of the original charge.

For best results:

- It is recommended that the system be initially charged with about 75% by weight of the original charge.
- Add the initial charge of Suva® refrigerant to the high-pressure side of the system (compressor *not* running) until the system and cylinder pressures equalize. Then connect to the low-pressure side of the system, start the compressor, and load the remainder of the refrigerant slowly to the suction side of the system. You should be removing liquid from the charging cylinder, and therefore should charge slowly to allow the refrigerant to flash (vaporize) before entering the compressor suction and avoid compressor damage.
- 9. Start up system, adjust charge size. Label system for the refrigerant and lubricant used. Start the system and let conditions stabilize. If the system is undercharged, add Suva® 404A (HP62) or Suva® 507 in small amounts (still removing liquid from the charging cylinder) until the system conditions reach the desired level. See the Pressure/Temperature Charts in this bulletin to compare pressures and temperatures for the Suva® refrigerant you are using.

Suva® refrigerants are more sensitive to charge size than CFCs. System performance will change quickly if the system is overcharged or undercharged. Sight glasses in the liquid line can be used in most cases as a guide, but system charge should also be determined by measuring system operating conditions (discharge and suction pressures, suction line temperature, compressor motor amps, superheat, etc.). Attempting to charge until the sight glass is clear may result in overcharging the refrigerant. Please read "How to Determine Suction Pressure, Superheat, and Subcool" on page 8.

Retrofit of R-22 Systems to DuPont™ Suva® 404A (HP62) or DuPont™ Suva® 507

The following detailed discussion is the recommended procedure for retrofitting R-22 systems to Suva® 404A (HP62) or Suva® 507.

1. Establish baseline performance with R-22. Collect system performance data while the R-22 is in the system. Check for correct refrigerant charge and operating conditions. The baseline data of temperatures and pressures at various points in the system (evaporator, condenser, compressor suction and discharge, superheat

and subcool, etc.) at normal operating conditions will be useful when optimizing operation of the system with the Suva® refrigerant. A **System Data Sheet** is included at the back of this document to record baseline data.

2. Drain mineral oil or alkylbenzene from the system and measure the volume removed. Leave the R-22 in the system. If mineral oil or alkylbenzene is the existing lubricant, it will have to be drained. This may require removing the compressor from the system, particularly with small hermetic compressors that have no oil drain port. In this case, the lubricant should be drained from the suction port on the compressor after the R-22 has been properly recovered. For an effective flush, it is important to remove at least 50% of the lubricant in all cases. Larger systems may require drainage from additional points in the system, particularly low spots around the evaporator. In systems with an oil separator, any lubricant present in the separator should also be drained.

In all cases, measure the volume of lubricant removed from the system. Record this information on the Retrofit Checklist (see Appendix). Compare this volume with the compressor/system specifications to ensure that the majority of lubricant has been removed. Consult the compressor manufacturer for recommendations on allowable residual MO/AB in POE lubricant. If poor system performance is noted on start-up, an additional lubricant change may be required.

- 3. Add POE lubricant; use the same volume as removed in Step 2. Start up system and operate for at least 24 hours, or more if system has complex piping. Charge the compressor with the same volume of new lubricant as the amount you removed from the system in step 2. Use a lubricant viscosity and grade recommended by the compressor manufacturer for the Suva® refrigerant you are using; or use a similar viscosity to the MO/AB you removed if compressor information is not available. A typical viscosity is 150 SUS or ISO 32 for many compressors.
- 4. Drain POE, and repeat steps 2 and 3 at least two more times. Continue flushing until MO/AB is less than 5% by weight or as recommended by compressor manufacturer. For an HFC refrigerant to operate properly in a retrofitted system, the residual MO/AB concentration must be very low. Repeatedly removing and replacing the POE

- will flush the old oil from the refrigeration system, providing that enough time is allowed with each change to circulate oil through the entire system.
- 5. **Recover the R-22 charge into a proper recovery cylinder.** Use normal service practices. If the correct charge size is not known, weigh the amount of refrigerant recovered.
- 6. **Replace the filter/drier.** It is routine practice to replace the filter/drier following system maintenance. Replacement driers are available that are compatible with Suva® refrigerants. See page 2 of this manual for additional information on driers.
- 7. Evacuate system and check for leaks. To remove air or other noncondensables in the system, evacuate the system to near full vacuum (29.9 inHg vacuum [500 microns] or less than 10 kPa).
- 8. Charge with Suva® refrigerant. Remove liquid only from charging cylinder. The proper cylinder position for liquid removal is indicated by arrows on the cylinder and cylinder box. Once liquid is removed from the cylinder, the refrigerant can be charged to the system as liquid or vapor as desired. Use the manifold gauges or a throttling valve to flash the liquid to vapor if required.

In general, the refrigeration system will require less weight of the Suva® refrigerant than of R-22. The optimum charge will vary depending on the system design and operating conditions, but for most systems the best charge size will be 75–90% by weight of the original charge.

For best results:

- It is recommended that the system be initially charged with about 75% by weight of the original charge.
- Add the initial charge of Suva® refrigerant to the high-pressure side of the system (compressor *not* running) until the system and cylinder pressures equalize. Then connect to the low-pressure side of the system, start the compressor, and load the remainder of the refrigerant slowly to the suction side of the system. You should be removing liquid from the charging cylinder, and therefore should charge slowly to allow the refrigerant to flash (vaporize) before entering the compressor suction and avoid compressor damage.

9. Start up system, adjust charge size. Label system for the refrigerant and lubricant used. Start the system and let conditions stabilize. If the system is undercharged, add Suva® 404A (HP62) or Suva® 507 in small amounts (still removing liquid from the charging cylinder) until the system conditions reach the desired level. See the Pressure/Temperature Charts in this bulletin to compare pressures and temperatures for the Suva® refrigerant you are using.

Suva® refrigerants are more sensitive to charge size than R-22. System performance will change quickly if the system is overcharged or undercharged. Sight glasses in the liquid line can be used in most cases as a guide, but system charge should also be determined by measuring system operating conditions (discharge and suction pressures, suction line temperature, compressor motor amps, superheat, etc.). Attempting to charge until the sight glass is clear may result in overcharging the refrigerant. Please read "How to Determine Suction Pressure, Superheat, and Subcool" below.

"Helpful Hints" For Retrofit From R-22 To Suva® 404A (HP62) or 507

Both Suva® 404A (HP62) and 507 have minimal "temperature glide" and can be used in systems that have flooded evaporators and condensers, as well as those that have direct expansion evaporators.

Since 404A (HP62) and 507 have higher cooling capacity than R-22, at lower evaporator temperatures the expansion device may need to be adjusted or replaced to maintain proper flow control and superheat settings. Estimated capacity comparison:

Evaporator Temperature	Capacity
30 to 50°F (-1 to 10°C)	Same
0°F (-18°C)	+6%
-40°F (-40°C)	+30%

Verify that compressor suction and discharge piping is the proper size to maintain proper refrigerant velocity and pressure drop.

Compressor discharge temperature will be lower than R-22.

The compressor discharge pressure will be higher with 404A (HP62) and 507. Various pressure switches may need to be adjusted to maintain proper operating conditions; for example:

- Evaporator pressure regulators
- Cut-in and cut-out pressure switches
- Condenser fan cycling pressure switches

- Head pressure controls
- Crankcase pressure regulators
- Others

Due to the higher oil miscibility with HFCs and POE, verify proper compressor oil sump levels.

Check with the compressor manufacturer for proper amperage load ratings.

Pressure/Temperature Charts - Introduction

How to Read the Pressure/Temperature Charts

Tables 1 through **5** contain pressure/temperature charts for the refrigerants discussed in this bulletin.

R-12, R-22 and Suva® 134a are all single component refrigerants with no temperature "glide" in the evaporator or condenser. Suva® 404A (HP62) and 507 have very small glide (less than 1°F [0.6°C]). For field service purposes, this glide can be neglected in calculating superheat and subcool. The evaporator temperature can be considered equal to the saturated vapor temperature at the compressor suction pressure; the condenser temperature can be considered equal to the saturated vapor temperature at the compressor discharge pressure. For Suva® 404A (HP62) and 507, the saturated vapor temperatures are listed in the tables.

How to Determine Suction Pressure, Superheat, and Subcool

Suction Pressure

Determine the expected evaporator temperature using the R-12, R-502 or R-22 column (from the baseline data you collected prior to the retrofit). Find the same expected evaporator temperature in the column for Suva® 134a, 404A (HP62) or 507. Note the corresponding pressure for this temperature. This is the suction pressure at which the system should operate.

Superheat and Subcool

Using the temperature column for Suva® 134a, 404A (HP62) and 507, the amount of superheat and subcool is calculated in the same manner as for the CFC or HCFC refrigerant.

Note: The amount of vapor superheat is always calculated from the actual saturated vapor temperature; the amount of liquid subcool is always calculated from the actual saturated liquid temperature.

Retrofit Checklist for DuPont™ Suva® 134a, DuPont™ Suva® 404A (HP62), or DuPont™ Suva® 507

 1.	Establish baseline performance with R-12, R-502, or R-22. (See data sheet for recommended data.)
 2.	Consult the original equipment manufacturer of the system components for recommendations on the following:
	Plastics compatibility
	Elastomers compatibility
	Lubricant (viscosity, manufacturer)
	Retrofit procedure to sustain warranty
 3.	Drain lubricant charge from the refrigerant system (unless polyol ester lubricant is already in the system).
	Remove majority of lubricant from system.
	Measure amount of lubricant removed and record:
 4.	Charge polyol ester lubricant using amount equivalent to amount of mineral oil removed. Run system with R-12, R-502, or R-22 for 24 hours, minimum.
 5.	Repeat lubricant drain and POE charging two more times or until mineral oil content is less than 5%.
 6.	Remove R-12, R-502, or R-22 charge from system. (Need 10–20 inHg vacuum [34–67 kPa].)
 7.	Replace filter drier with new drier approved for use with Suva® 134a, Suva® 404A (HP62), or Suva® 507.
 8.	Reconnect system and evacuate with vacuum pump. (Evacuate to full vacuum [29.9 inHg vacuum/0.14 kPa].)
 9.	Leak-check system. (Reevacuate system following leak check.)
10.	Charge system with Suva®.
	• Initially charge 75% by weight of original equipment manufacturer R-12, R-502, or R-22 charge.
	Amount of refrigerant charged:
 11.	Start equipment and adjust charge until desired operating conditions are achieved. If low in charge, add in increments of 2–3% of original R-12, R-502, or R-22 charge.
	Amount of refrigerant charged:
	Total refrigerant charged:
 12.	Label components and system for type of refrigerant (Suva® 134a, Suva® 404A (HP62), or Suva® 507) and lubricant (polyol ester).

Retrofit is complete.

System Data Sheet

Equipment Mfa :			
Equipmentivity		Compressor Mfg.:	
Model No.:		Model No.:	
Serial No.:			
Original Charge Size:		Original Lubricant:	
		•	
		Lubricant Charge Size:	
		•••	
		Additional Charge Size:	
Drier Mfg.:		Drier Type (check one):	
Model No.:		Loose Fill:	
		Solid Core:	
Condenser Cooling Medium (air/water):			
Expansion Device (check one):	Canillary Tube:		
Expansion Device (check one).			
If Francisca Value	Expansion valve		
If Expansion Valve:			
Manufacturer:			
Model No.:			
Control/Set Point:			
Location of Sensor:			
Other System Controls (ex.: head press controls	rol), Describe:		
(circle units used where applicable) Date/Time			
Refrigerant			
Charge Size (lb, oz/g)			
Ambient Temp. (°F/°C)			
Relative Humidity			
Compressor:		I	
C+: T (0F/0C)			
Suction T (°F/°C)			
Suction P (psi/kPa/bar)			
Suction P (psi/kPa/bar)			
Suction P (psi/kPa/bar) Discharge T (°F/°C)			
Suction P (psi/kPa/bar) Discharge T (°F/°C) Discharge P (psi/kPa/bar)			
Suction P (psi/kPa/bar) Discharge T (°F/°C) Discharge P (psi/kPa/bar) Box/CaseT (°F/°C) Evaporator: Refrigerant Inlet T (°F/°C)			
Suction P (psi/kPa/bar) Discharge T (°F/°C) Discharge P (psi/kPa/bar) Box/CaseT (°F/°C) Evaporator:			
Suction P (psi/kPa/bar) Discharge T (°F/°C) Discharge P (psi/kPa/bar) Box/CaseT (°F/°C) Evaporator: Refrigerant Inlet T (°F/°C)			
Suction P (psi/kPa/bar) Discharge T (°F/°C) Discharge P (psi/kPa/bar) Box/CaseT (°F/°C) Evaporator: Refrigerant Inlet T (°F/°C) Refrigerant Outlet T (°F/°C)			
Suction P (psi/kPa/bar) Discharge T (°F/°C) Discharge P (psi/kPa/bar) Box/CaseT (°F/°C) Evaporator: Refrigerant Inlet T (°F/°C) Refrigerant Outlet T (°F/°C) Coil Air/H ₂ O In T (°F/°C))		
Suction P (psi/kPa/bar) Discharge T (°F/°C) Discharge P (psi/kPa/bar) Box/CaseT (°F/°C) Evaporator: Refrigerant Inlet T (°F/°C) Refrigerant Outlet T (°F/°C) Coil Air/H ₂ O In T (°F/°C)			
Suction P (psi/kPa/bar) Discharge T (°F/°C) Discharge P (psi/kPa/bar) Box/CaseT (°F/°C) Evaporator: Refrigerant Inlet T (°F/°C) Refrigerant Outlet T (°F/°C) Coil Air/H ₂ O In T (°F/°C) Coil Air/H ₂ O Out T (°F/°C) Refrigerant T at Superheat Ctl. Pt. (°F/°C) Condenser: Refrigerant Inlet T (°F/°C)			
Suction P (psi/kPa/bar) Discharge T (°F/°C) Discharge P (psi/kPa/bar) Box/CaseT (°F/°C) Evaporator: Refrigerant Inlet T (°F/°C) Refrigerant Outlet T (°F/°C) Coil Air/H ₂ O In T (°F/°C) Coil Air/H ₂ O Out T (°F/°C) Refrigerant T at Superheat Ctl. Pt. (°F/°C) Condenser: Refrigerant Inlet T (°F/°C)			
Suction P (psi/kPa/bar) Discharge T (°F/°C) Discharge P (psi/kPa/bar) Box/CaseT (°F/°C) Evaporator: Refrigerant Inlet T (°F/°C) Refrigerant Outlet T (°F/°C) Coil Air/H ₂ O In T (°F/°C) Refrigerant T at Superheat Ctl. Pt. (°F/°C) Condenser: Refrigerant Inlet T (°F/°C) Refrigerant Outlet T (°F/°C)			
Suction P (psi/kPa/bar) Discharge T (°F/°C) Discharge P (psi/kPa/bar) Box/CaseT (°F/°C) Evaporator: Refrigerant Inlet T (°F/°C) Refrigerant Outlet T (°F/°C) Coil Air/H ₂ O In T (°F/°C) Coil Air/H ₂ O Out T (°F/°C) Refrigerant T at Superheat Ctl. Pt. (°F/°C) Condenser: Refrigerant Inlet T (°F/°C)			
Suction P (psi/kPa/bar) Discharge T (°F/°C) Discharge P (psi/kPa/bar) Box/CaseT (°F/°C) Evaporator: Refrigerant Inlet T (°F/°C) Refrigerant Outlet T (°F/°C) Coil Air/H ₂ O In T (°F/°C) Refrigerant T at Superheat Ctl. Pt. (°F/°C) Condenser: Refrigerant Inlet T (°F/°C) Refrigerant Outlet T (°F/°C)			
Suction P (psi/kPa/bar) Discharge T (°F/°C) Discharge P (psi/kPa/bar) Box/CaseT (°F/°C) Evaporator: Refrigerant Inlet T (°F/°C) Refrigerant Outlet T (°F/°C) Coil Air/H ₂ O In T (°F/°C) Refrigerant T at Superheat Ctl. Pt. (°F/°C) Condenser: Refrigerant Inlet T (°F/°C) Refrigerant Outlet T (°F/°C) Condenser: Refrigerant Outlet T (°F/°C) Coil Air/H ₂ O In T (°F/°C) Coil Air/H ₂ O In T (°F/°C)			
Suction P (psi/kPa/bar) Discharge T (°F/°C) Discharge P (psi/kPa/bar) Box/CaseT (°F/°C) Evaporator: Refrigerant Inlet T (°F/°C) Refrigerant Outlet T (°F/°C) Coil Air/H ₂ O In T (°F/°C) Coil Air/H ₂ O Out T (°F/°C) Refrigerant T at Superheat Ctl. Pt. (°F/°C Condenser: Refrigerant Inlet T (°F/°C) Refrigerant Outlet T (°F/°C) Coil Air/H ₂ O In T (°F/°C) Coil Air/H ₂ O Out T (°F/°C) Exp. Device Inlet T (°F/°C)			
Suction P (psi/kPa/bar) Discharge T (°F/°C) Discharge P (psi/kPa/bar) Box/CaseT (°F/°C) Evaporator: Refrigerant Inlet T (°F/°C) Refrigerant Outlet T (°F/°C) Coil Air/H ₂ O In T (°F/°C) Coil Air/H ₂ O Out T (°F/°C) Refrigerant T at Superheat Ctl. Pt. (°F/°C) Condenser: Refrigerant Inlet T (°F/°C) Refrigerant Outlet T (°F/°C) Coil Air/H ₂ O In T (°F/°C) Coil Air/H ₂ O Out T (°F/°C) Exp. Device Inlet T (°F/°C) Motor Amps			

Appendix

Table 1 Pressure/Temperature Chart DuPont™ Suva® 134a/R-12 Saturation Properties

English Units

SI Units

	English Units			kPa Saturation Temperature, °C Saturation Temperature -59 -53 -45 -40 -37 -32 -30 -26 -24 -21 -20 -17 -16 -13 -12 -10 -9 -7 -6 -4 -4 -2 -1 1 2 3 4 5 6 7 8 9 12 12 16 16 19 19		
Pressure, psi	R-12 Saturation Temperature, °F	HFC-134a Saturation Temperature, °F	Pressure,	kPa	Saturation	HFC-134a Saturation Temperature, °C
15*	-49	-40	25		-59	-53
10*	-38	-30	50		-45	-40
5*	-29	-22	75		-37	-32
0	-22	– 15	100		-30	-26
5	-9	-3	125		-24	-21
10	2	7	150		-20	-17
15	10	15	175		-16	-13
20	18	22	200		-12	-10
25	26	29	225		-9	-7
30	32	35	250		-6	-4
35	38	40	275		-4	-2
40	43	45	300		–1	1
45	48	50	325		2	
50	53	54	350		4	
55	58	58	375			
60	62	62	400		8	9
65	66	66	450			12
70	70	69	500			
75	74	73	550			
80	77	76	600			22
85	81	79	650		25	24
90	84	82	700		28	27
95	87	85	750		30	29
100	90	88	800		33	31
110	96	93	900		37	36
120	102	98	1000		42	39
130	107	103	1200		49	46
140	112	107	1400		56	52
150	117	112	1600		62	58
165	123	118	1800		68	63
180	130	123	2000		73	67
195	136	129	2200		78	72
210	141	134	2400		82	76
225	147	139	2600		86	79
240	152	143	2800		90	83
255	157	148	3000		94	86
270	162	152	3200		98	89
285	166	156	3400		101	93
300	170	160	3600		104	95

^{*}inHg, vacuum

Table 2
Pressure/Temperature Chart
DuPont™ Suva® 404A (HP62)/R-502 Saturation Properties

SI Units

Pressure, psi	R-502 Sat. Temp, °F	404A (HP62) Sat. Temp, °F	Pressure psi	R-502 Sat. Temp, ° F	404A (HP62) Sat. Temp, ° F	Pressure, kPa	R-502 Sat. Temp, °C	404A (HP62) Sat. Temp, °C	Pressure kPa	R-502 Sat. Temp, °C	404A (HP62 Sat. Temp, °C
25*	-108	-107	58	24	22	25	- 72	- 71	1450	34	31
20*	-88	- 87	60	26	23	50	-60	-59	1500	35	32
15*	- 75	- 75	62	27	25	75	-52	-52	1550	37	34
10*	-65	-65	64	29	26	100	-4 6	-46	1600	38	35
5*	- 56	<i>–</i> 57	66	30	28	125	-4 1	-4 1	1650	39	36
4*	- 55	-56	68	32	29	150	-37	-37	1700	41	37
3*	<i>–</i> 54	-54	70	33	30	175	-33	-34	1750	42	38
2*	-53	-53	72	34	32	200	-30	-30	1800	43	40
1*	- 52	-52	74	36	33	225	-27	-28	1900	46	42
0	- 50	-50	76	37	34	250	-24	-25	2000	48	44
2	-45	-45	78	38	35	275	-22	-22	2100	50	46
4	-40	-4 1	80	40	36	300	– 19	-20	2200	52	48
6	-36	-37	82	41	37	325	–17	-18	2300	54	50
8	-32	-33	84	42	38	350	– 15	-16	2400	56	52
10	-29	-30	86	43	40	375	– 13	-14	2500	58	54
12	-25	-26	88	45	41	400	-11	-12	2600	60	56
14	-22	-23	90	46	43	425	-9	-10	2700	62	57
16	-19	-20	92	47	44	450	-8	- 9	2800	64	59
18	-16	-18	94	48	45	475	- 6	- 7	2900	65	61
20	-13	–15	96	49	46	500	-4	- 6			
22	-11	-12	98	50	47	550	– 1	- 3			
24	-8	-10	100	51	48	600	2	0			
26	-6	– 7	105	54	51	650	4	2			
28	- 3	- 5	110	57	53	700	7	5			
30	-1	-3	115	60	56	750	9	7			
32	1	– 1	120	62	58	800	11	9			
34	3	2	125	64	60	850	13	11			
36	5	3	130	67	63	900	15	13			
38	7	5	135	69	65	950	17	15			
40	9	7	140	71	67	1000	19	17			
42	11	9	145	73	69	1050	21	19			
44	13	11	150	75	71	1100	23	20			
46	15	12	175	85	81	1150	25	22			
48	16	14	200	95	89	1200	26	24			
50	18	16	250	111	104	1250	28	25			
52	20	17	300	125	118	1300	29	27			
54	21	19	350	137	129	1350	31	28			
56	23	20	400	148	140	1400	32	30			

*inHg, vacuum

Table 3 Pressure/Temperature Chart DuPont™ Suva® 507/R-502 Saturation Properties

SI Units

	English Units							5i Units					
Pressure, psi	R-502 Sat. Temp, °F	507 Sat. Temp, °F	Pressure psi	R-502 Sat. Temp, °F	507 Sat. Temp, °F		Pressure, kPa	R-502 Sat. Temp, °C	507 Sat. Temp, °C	Pressure kPa	R-502 Sat. Temp, °C	507 Sat. Temp, °C	
25*	-108	-110	58	24	19		25	-72	-72	1000	19	16	
20*	-88	-90	60	26	21		50	-60	-61	1050	21	17	
15*	- 75	–77	62	27	22		75	-52	-53	1100	23	19	
10*	-65	-67	64	29	24		100	-46	-47	1150	25	21	
5*	-56	-61	66	30	25		125	-41	-43	1200	26	22	
4*	-55	- 59	68	32	26		150	-37	-39	1250	28	24	
3*	-54	-58	70	33	28		175	-33	-35	1300	29	25	
2*	-53	– 57	72	34	29		200	-30	-32	1350	31	27	
1*	-52	-56	74	36	30		225	-27	-29	1400	32	28	
0	-50	-54	76	37	32		250	-24	-26	1450	34	30	
2	-45	-48	78	38	33		275	-22	-24	1500	35	31	
4	-40	-44	80	40	34		300	-19	-22	1550	37	32	
6	-36	-39	82	41	35		325	-17	-19	1600	38	34	
8	-32	-36	84	42	37		350	-15	-17	1650	39	35	
10	-29	-32	86	43	38		375	-13	-15	1700	41	36	
12	-25	-29	88	45	39		400	-11	-14	1750	42	37	
14	-22	-26	90	46	40		425	-9	-12	1800	43	38	
16	-19	-23	92	47	41		450	-8	-10	1900	46	41	
18	-16	-20	94	48	42		475	-6	-9	2000	48	43	
20	-13	-17	96	49	43		500	-4	- 7	2100	50	45	
22	-11	-15	98	50	44		550	-1	-4	2200	52	47	
24	-8	-12	100	51	46		600	2	-2	2300	54	49	
26	-6	-10	105	54	48		650	4	1	2400	56	51	
28	-3	-8	110	57	51		700	7	4	2500	58	53	
30	–1	-6	115	60	53		750	9	6	2600	60	54	
32	1	-3	120	62	55		800	11	8	2700	62	56	
34	3	– 1	125	64	58		850	13	10	2800	64	58	
36	5	1	130	67	60		900	15	12	2900	65	59	
38	7	3	135	69	62		950	17	14				
40	9	4	140	71	64								
42	11	6	145	73	66								
44	13	8	150	75	69								
46	15	10	175	85	78								
48	16	11	200	95	87								
50	18	13	250	111	102								
52	20	15	300	125	115								
54	21	16	350	137	127								
56	23	18	400	148	137								

^{*}inHg, vacuum

Table 4
Pressure/Temperature Chart
DuPont™ Suva® 404A (HP62)/R-22 Saturation Properties

SI Units

Pressure, psi	R-22 Sat. Temp, °F	404A (HP62) Sat. Temp, °F	Pressure psi	R-22 Sat. Temp, °F	404A (HP62) Sat. Temp, °F	Pressure, kPa	R-22 Sat. Temp, °C	404A (HP62) Sat. Temp, °C	Pressure kPa	R-22 Sat. Temp, °C	404A (HP62) Sat. Temp, °C
25*	-100	-107	58	32	22	25	- 67	-71	1450	38	31
20*	-80	-87	60	34	23	50	-55	-59	1500	39	32
15*	-66	- 75	62	35	25	75	–47	-52	1550	40	34
10*	- 56	-65	64	37	26	100	-4 1	-46	1600	42	35
5*	-48	- 57	66	38	28	125	-36	-4 1	1650	43	36
4*	-4 7	-56	68	40	29	150	-32	-37	1700	44	37
3*	-4 5	- 54	70	41	30	175	-28	-34	1750	46	38
2*	-44	-53	72	42	32	200	-25	-30	1800	47	40
1*	-43	- 52	74	44	33	225	-22	-28	1900	49	42
0	-4 1	-50	76	45	34	250	-20	-25	2000	51	44
2	-36	-4 5	78	46	35	275	–17	-22	2100	53	46
4	-32	-4 1	80	48	36	300	-15	-20	2200	56	48
6	-28	-37	82	49	37	325	-12	-18	2300	58	50
8	-24	-33	84	50	38	350	-10	-16	2400	59	52
10	-20	-30	86	51	40	375	-8	-14	2500	61	54
12	–17	-26	88	52	41	400	– 7	-12	2600	63	56
14	-14	-23	90	54	43	425	- 5	–10	2700	65	57
16	-11	-20	92	55	44	450	-3	-9	2800	67	59
18	-8	-18	94	56	45	475	– 1	- 7	2900	68	61
20	- 5	-15	96	57	46	500	0	-6			
22	-2	-12	98	58	47	550	3	-3			
24	0	-10	100	59	48	600	6	0			
26	2	– 7	105	62	51	650	8	2			
28	5	- 5	110	64	53	700	11	5			
30	7	-3	120	69	58	750	13	7			
32	9	– 1	125	72	60	800	15	9			
34	11	2	130	74	63	850	18	11			
36	13	3	135	76	65	900	20	13			
38	15	5	140	78	67	950	22	15			
40	17	7	145	81	69	1000	23	17			
42	19	9	150	83	71	1050	25	19			
44	21	11	175	93	81	1100	27	20			
46	23	12	200	101	89	1150	29	22			
48	24	14	250	117	104	1200	30	24			
50	26	16	300	131	118	1250	32	25			
52	28	17	350	143	129	1300	33	27			
54	29	19	400	154	140	1350	35	28			
56	31	20				1400	36	30			

^{*}inHg, vacuum

Table 5 Pressure/Temperature Chart DuPont™ Suva® 507/R-22 Saturation Properties

SI Units

		<u> </u>	Ullits			3i Offics						
Pressure, psi	R-22 Sat. Temp, °F	507 Sat. Temp, °F	Pressure psi	R-22 Sat. Temp, °F	507 Sat. Temp, °F	Pressure, kPa	R-22 Sat. Temp, °C	507 Sat. Temp, °C	Pressure kPa	R-22 Sat. Temp, °C	507 Sat. Temp, °C	
25*	-100	-110	58	32	19	25	-67	-72	1000	23	16	
20*	-80	-90	60	34	21	50	-55	-61	1050	25	17	
15*	-66	–77	62	35	22	75	–47	-53	1100	27	19	
10*	-56	-67	64	37	24	100	-41	-47	1150	29	21	
5*	-48	-61	66	38	25	125	-36	-43	1200	30	22	
4*	-47	-59	68	40	26	150	-32	-39	1250	32	24	
3*	-45	-58	70	41	28	175	-28	-35	1300	33	25	
2*	-44	– 57	72	42	29	200	-25	-32	1350	35	27	
1*	-43	-56	74	44	30	225	-22	-29	1400	36	28	
0	-41	-54	76	45	32	250	-20	-26	1450	38	30	
2	-36	-48	78	46	33	275	–17	-24	1500	39	31	
4	-32	-44	80	48	34	300	-15	-22	1550	40	32	
6	-28	-39	82	49	35	325	-12	-19	1600	42	34	
8	-24	-36	84	50	37	350	-10	-17	1650	43	35	
10	-20	-32	86	51	38	375	-8	-15	1700	44	36	
12	-17	-29	88	52	39	400	- 7	-14	1750	46	37	
14	-14	-26	90	54	40	425	-5	-12	1800	47	38	
16	-11	-23	92	55	41	450	-3	-10	1900	49	41	
18	-8	-20	94	56	42	475	-1	-9	2000	51	43	
20	-5	-17	96	57	43	500	0	- 7	2100	53	45	
22	-2	-15	98	58	44	550	3	-4	2200	56	47	
24	0	-12	100	59	46	600	6	-2	2300	58	49	
26	2	-10	105	62	48	650	8	1	2400	59	51	
28	5	-8	110	64	51	700	11	4	2500	61	53	
30	7	-6	120	69	55	750	13	6	2600	63	54	
32	9	-3	125	72	58	800	15	8	2700	65	56	
34	11	- 1	130	74	60	850	18	10	2800	67	58	
36	13	1	135	76	62	900	20	12	2900	68	59	
38	15	3	140	78	64	950	22	14				
40	17	4	145	81	66							
42	19	6	150	83	69							
44	21	8	175	93	78							
46	23	10	200	101	87							
48	24	11	250	117	102							
50	26	13	300	131	115							
52	28	15	350	143	127							
54	29	16	400	154	137							
56	31	18										

^{*}inHg, vacuum

Table 6 DuPont™ Suva® 134a (R-134a) Physical Properties

Physical Property	Unit	DuPont™ Suva® 134a (R-134a)	R-12
Boiling Point at 1 atm	°F	–14.9	-21.6
	°C	–26.1	-29.8
Vapor Pressure	psia	96.61	94.51
Sat'd Liquid at 77°F (25°C)	kPa	666.1	651.6
Liquid Density	lb/ft³	75.28	81.84
at 77°F (25°C)	kg/m³	1,206	1,311
Density	lb/ft³	2.02	2.32
Sat'd Vapor at 77°F (25°C)	kg/m³	32.4	37.2
Ozone-Depletion Potential Compared with CFC-12	CFC-12 = 1	0	1
Global Warming Potential Compared with CO ₂	CO ₂ = 1	1300	8500

Table 7
DuPont™ Suva® 404A (HP62) and DuPont™ Suva® 507 (R-507) Physical Properties

Physical Property	Unit	DuPont™ Suva® 404A (HP62)	DuPont™ Suva® 507 (R-507)	R-502	R-22
Boiling Point at 1 atm	°F	-51.6	-52.1	-49.8	-41.4
	°C	-46.5	-46.7	-45.4	-40.8
Vapor Pressure	psia	182	187	168	151
Sat'd Liquid at 77°F (25°C)	kPa	1,255	1,287	1,162	1,041
Liquid Density	lb/ft³	65.45	65.5	75.9	74.5
at 77°F (25°C)	kg/m³	1,048	1,049	1,217	1193
Density	lb/ft³	4.0	4.3	4.2	2.8
Sat'd Vapor at 77°F (25°C)	kg/m³	64.1	68.9	67.3	44.9
Ozone-Depletion Potential Compared with R-12	R-12 = 1	0	0	0.23	0.05
Global Warming Potential Compared with CO ₂	CO ₂ = 1	3260	3300	5494	1700

Table 8 Compositions of DuPont™ Suva® Refrigerants

Compositions, wt%	HFC-125	HFC-143a	HFC-134a
Suva® 404A (HP62)	44	52	4
Suva® 507 (R-507)	50	50	
Suva® 134a (R-134a)			100

For Further Information:

DuPont Fluorochemicals Wilmington, DE 19880-0711 (800) 235-SUVA www.suva.dupont.com

Europe

DuPont de Nemours International S.A. 2 Chemin du Pavillon P.O. Box 50 CH-1218 Le Grand-Saconnex Geneva, Switzerland 41-22-717-5111

Canada

DuPont Canada, Inc. P.O. Box 2200, Streetsville Mississauga, Ontario Canada L5M 2H3 (905) 821-3300

Mexico

DuPont, S.A. de C.V. Homero 206 Col. Chapultepec Morales C.P. 11570 Mexico, D.F. 52-5-722-1100

South America

DuPont do Brasil S.A. Alameda Itapecuru, 506 Alphaville 06454-080 Barueri São Paulo, Brazil 55-11-7266-8263

DuPont Argentina S.A. Casilla Correo 1888 Correo Central 1000 Buenos Aires, Argentina 54-1-311-8167

Pacific

DuPont Australia P.O. Box 930 North Sydney, NSW 2060 Australia 61-2-99236111

Japan

Mitsui DuPont Fluorochemicals Co., Ltd. Chiyoda Honsha Bldg. 5-18, 1-Chome Sarugakucho Chiyoda-Ku, Tokyo 101-0064 Japan 81-3-5281-5805

Asia

DuPont Taiwan P.O. Box 81-777 Taipei, Taiwan 886-2-514-4400

DuPont China Limited P.O. Box TST 98851 1122 New World Office Bldg. (East Wing) Tsim Sha Tsui Kowloon, Hong Kong Phone: 852-734-5398 Fax: 852-236-83516

DuPont Thailand Ltd. 9-11 Floor, Yada Bldg. 56 Silom Road Suriyawongse, Bankrak Bangkok 10500 Phone: 66-2-238-0026 Fax: 66-2-238-4396

DuPont China Ltd. Rm. 1704, Union Bldg. 100 Yenan Rd. East Shanghai, PR China 200 002 Phone: 86-21-328-3738 Telex: 33448 DCLSH CN Fax: 86-21-320-2304 DuPont Far East Inc. 6th Floor Bangunan Samudra No. 1 JLN. Kontraktor U1/14, SEK U1 Hicom-Glenmarie Industrial Park 40150 Shah Alam, Selangor Malaysia Phone 60-3-517-2534

DuPont Korea Inc. 4/5th Floor, Asia Tower #726, Yeoksam-dong, Kangnam-ku Seoul, 135-082, Korea 82-2-721-5114

DuPont Singapore Pte. Ltd. 1 Maritime Square #07 01 World Trade Centre Singapore 0409 65-273-2244

DuPont Far East, Philippines 8th Floor, Solid Bank Bldg. 777 Paseo de Roxas Makati, Metro Manila Philippines Phone: 63-2-818-9911 Fax: 63-2-818-9659

DuPont Far East Inc. 7A Murray's Gate Road Alwarpet Madras, 600 018, India 91-44-454-029

DuPont Far East Inc.—Pakistan 9 Khayaban-E-Shaheen Defence Phase 5 Karachi, Pakistan 92-21-533-350

DuPont Far East Inc. P.O. Box 2553/Jkt Jakarta 10001, Indonesia 62-21-517-800

The information contained herein is based on technical data and tests which we believe to be reliable and is intended for use by persons having technical skill, at their own discretion and risk. Because conditions of use are outside of DuPont control, we can assume no liability for results obtained or damages incurred through the application of the data presented.

© 2004. E. I. du PONT de NEMOURS AND COMPANY. ALL RIGHTS RESERVED.

NO PART OF THIS MATERIAL MAY BE REPRODUCED, STORED IN A RETRIEVAL SYSTEM OR TRANSMITTED IN ANY FORM OR BY ANY MEANS ELECTRONIC, MECHANICAL, PHOTOCOPYING, RECORDING, OR OTHERWISE WITHOUT THE PRIOR WRITTEN PERMISSION OF DUPONT.

